

Unit for the Cultivation of Microalgae 18 m²

DETAIL DESIGN

INSTRUMENTATION AND ELECTRICAL PART

Customer : Zürich University of Applied Sciences ZHAW

**Location : Institute of Natural Resource Sciences IUNR
Grüental
CH-8820 Wädenswil
Switzerland**

**Designed by : Ing. Tomáš Harašta
Ing. Jan Vykoupil**

Checked by : Ing. Petr Dvořák

Approved by : Ing. Karel Kostelník

Specification of instruments

CONTENT

1. FIELD INSTRUMENTATION	2
2. CONTROL CUBICLE	9

1. Field Instrumentation

LISA 001 LEVEL OF SUSPENSION IN TANK

- .01 **Name:** Screw-in Transmitter. Ceramic sensor, flush **1 pc**
Description:
Pressure in mH₂O, Input: (mH₂O) 1,0m, Output: 0...10V/3-wire, Accuracy: 0,35%,
Electrical connection: Male and female plug ISO 4400(IP65), Mechanical connection: G1
1/2", Seals: FKM, Pressure port: Stainless steel 1.4571, Diaphragm: Ceramics Al₂O₃
96%, Special version: standard
Range: 0÷1 m is 0÷10 V
Order No.: LMK 351 471-1000-3-3-100-M00-1-1-2-000
Manufacturer/Supplier: BD SENSORS/JSP s.r.o.

PIC 001 OUTPUT PRESSURE OF PUMP

- .01 **Name:** Industrial Pressure Transmitter. Ceramic sensor, flush **1 pc**
Description:
Pressure gauge, Input: 0,6bar, Output: 0...10V/3-wire, Accuracy: 0,5%, Electrical
connection: Male and female plug ISO 4400(IP65), Mechanical connection: G1/2" DIN
3852, Seals: FKM, Pressure port: Stainless steel 1.4571, Diaphragm: Ceramics Al₂O₃
96%, Special version: standard
Range: 0÷60 kPa is 0÷10 V
Order No.: DMK 331 250-6000-3-5-100-100-1-1-2-000
Manufacturer/Supplier: BD SENSORS/JSP s.r.o.

LIC 002 LEVEL OF SUSPENSION ON PLATFORM

- .01 **Name:** Ultrasonic sensor **1 pc**
Description:
Ultrasonic sensor, Output: 4...20mA, Accuracy: ±0,5%, Connection: V1
connector(M12x1) 4-pin, Mechanical connection: M12x1, Material: brass, nickel-plated,
Transducer: epoxy resin/hollow glass sphere mixture; foam polyurethane, cover PBT
Sensing Range: 15...120 mm
Adjustment Range: 20...120 mm
Order No.: UB120-12GM-I-V1 (038310)
Manufacturer/Supplier: PEPPERL+FUCHS/ PEPPERL+FUCHS
- .02 **Name:** Connector V1 with cable **1 pc**
Description:
Female connector M12, Protection degree: IP67, Cable lenght: 10m
Cable lenght: 10 m
Order No.: V1-G-10M-PVC
Manufacturer/Supplier: PEPPERL+FUCHS/ PEPPERL+FUCHS

QIC 001 **pCO2**

- .01 **Name:** Dissolved carbon dioxide sensor **1 pc**
Description:
Lower detection limit 10mbar, Accuracy: $\pm 10\%$ (pCO₂ 10 to 900mbar), $\pm 15\%$ (pCO₂ > 900mbar), Response time: 90% of final value < 120 sec at 25°C, Measuring principle: Potentiometric Severinghaus, Cable connection: VP(IP68), Conector design: straight, Sensor body: 316L stainless steel, Membrane material: silicone(reinforced with steel mesh), Surface roughness of wetted parts: N5(R_a=0,4µin/16µin), O-ring material: Viton, silicone(FDA compliant), Sensor diameter: 12mm, Temperature compensation: Automatic, Temperature sensor: Pt1000, Measuring temperature range: 0 to 60°C, Sterilization temperature: $\leq 130^\circ\text{C}$, Measuring pressure resistance: 0,2 to 2 bar, Mechanical pressure resistance: 3 bar at 25°C
Measuring range: 10...1000 mbar CO₂
Order No.: InPro5000i/12/120 (30013606)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .02 **Name:** Connector AK9 with cable **1 pc**
Description:
Female connector, Protection degree: IP68, Cable lenght: 5m
Cable lenght: 5 m
Order No.: AK9/5m (59902213)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .03 **Name:** Housing **1 pc**
Description:
Wetted parts: Stainless 316L, Surface finish(O-ring groove/Other): N5/N5(R_a 16/Ra 16), O-ring: Silicone-FDA-USP VI, Sensor fitting: Pg 13,5, Temperature range: 0-140°C, Pressure rating: Max. 16bar
Order No.: InFit761/WS/0070/4435/D00/Si9-
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .04 **Name:** Transmitter M400 **1 pc**
Description:
Power supply: 100 to 240 V AC or 20 to 30 V DC, Frequency for AC: 50 to 60Hz, Current output: 4x0/4 to 20 mA, 22mA alarm, Service interface: USB, Display: Backlit LCD, 4 lines, Languages: 8, Ambient temperature: -10 to 50°C, Relative humidity: 0 to 95% non-condensing, Rating/Approvals: IP65, PID process controller: Yes, Hold input: Yes, Control input: yes, Alarm contact: Yes, Measurement parameters: D.O. saturation or concentration and temperature, ISM: Plug&Measure, Advanced Diagnostics (Lifetime indicator, Adaptive calibration timer, CIP/SIP counter etc.), Measuring current (Air): 25 to 130 nA at 25°C, D.O. saturation range: 0 to 500%, D.O. concentration range: 0,00 to 20,00 ppm, Measurement error: $\pm 0,5\%$ of full scale reading, Measurement resolution: 30pA, Temperature input: NTC 22kΩ, Temperature compensation: Automatic, Temperature measuring range: -10 to 80°C, Calibration: 1-point (slope or offset calibration), process calibration (slope or offset calibration)
Order No.: M400 Type 3 (52121350)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO

QI 002 pH
TI 001 TEMPERATURE OF SUSPENSION

- .01 **Name:** ISM pH sensor with sterilization resistant glass **1 pc**
Description:
Plug head: AK9(IP68), Pg 13,5, Shaft diameter: 12mm, Temperature sensor: Pt1000, Measuring temperature range: 0 to 100°C, Sterilization temperature: ≤140°C, Pressure: 0 to 4 barg, Reference systém: Argenthal with silver-ion trap, Type of junction: Ceramic, Reference electrolyte: Pre-pressurized liquid, Lenght: 120mm, Sterilizable: Yes, Autoclavable: Yes
pH range: 0-12 pH
Order No.: InPro3253i/SG/120 (52005377)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .02 **Name:** Connector AK9 with cable **1 pc**
Description:
Female connector, Protection degree: IP68, Cable lenght: 5m
Cable lenght: 5 m
Order No.: AK9/5m (59902213)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .03 **Name:** Housing **1 pc**
Description:
Wetted parts: Stainless 316L, Surface finish(O-ring groove/Other): N5/N5(R_a 16/R_a 16), O-ring: Silicone-FDA-USP VI, Sensor fitting: Pg 13,5, Temperature range: 0-140°C, Pressure rating: Max. 16bar
Order No.: InFit761/WS/0070/4435/D00/Si9-
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .04 **Name:** Transmitter M300 ISM 1 Channel Multi 1/2DIN, wall **1 pc**
Description:
Power supply: 100 to 240 V AC or 20 to 30 V DC, Frequency for AC: 50 to 60Hz, Current output: 2x0/4 to 20 mA, 22mA alarm, Service interface: USB, Display: Backlit LCD, 4 lines, Languages: 8, Ambient temperature: -10 to 50°C, Relative humidity: 0 to 95% non-condensing, Rating/Approvals: IP65, PID process controller: Yes, Hold input: Yes, Control input: yes, Alarm contact: Yes, M300 for ISM: "Plug and Measure" feature, Measurement parameters: pH, mV and temperature, pH display range: -1 to 15 pH, Resolution: 0,01 pH, 1mV, Relative accuracy: ±0,03% pH, ±2 mV, Temperature input: PT1000, Temperature compensation: Automatic/manual, Temperature measuring range: -30 to 150°C, Temperature resolution: 0,1°C, Temperature measurement error: ±0,25°C, Calibration: 1 or 2 point calibration, process calibration
Order No.: M300 ISM 1 Channel Multi 1/2DIN, wall (52121355)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO

QI 003 O2

- .01 **Name:** Optical oxygen sensor **1 pc**
Description:
 Accuracy: $\leq \pm[1\%+8\text{ppb}]$, Response time at 25°C: 98% of final value < 70 sec,
 Measuring principle: Optical, Cable connection: VP8(IP68), Sensor body: 316L stainless steel, O₂ selective membrane material: PTFE/silicone, Surface roughness of wetted parts: N5(R_a=0,4µin/16µin), Wetted sensor parts: PTFE, Wetted O-rings: EPDM, Sensor diameter: 12mm, Measuring temperature range: 5 to 60°C, Mechanical temperature resistance: -20 to 140°C, Measuring pressure resistance: 0,2 to 6 bar, Mechanical pressure resistance: Maximum 6 bar
Operating range: 8 ppb to 60% O₂ saturation
Order No.: InPro6860i/12/120 (30014100)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .02 **Name:** Connector VP8 with cable **1 pc**
Description:
 Female connector, Protection degree: IP68, Cable lenght: 5m
Cable lenght: 5 m
Order No.: VP8-ST/5m (52300355)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .03 **Name:** Housing **1 pc**
Description:
 Wetted parts: Stainless 316L, Surface finish(O-ring groove/Other): N5/N5(R_a 16/Ra 16), O-ring: Silicone-FDA-USP VI, Sensor fitting: Pg 13,5, Temperature range: 0-140°C, Pressure rating: Max. 16bar
Order No.: InFit761/WS/0070/4435/D00/Si9-
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO
- .04 **Name:** Transmitter M400 **1 pc**
Description:
 Power supply: 100 to 240 V AC or 20 to 30 V DC, Frequency for AC: 50 to 60Hz, Current output: 4x0/4 to 20 mA, 22mA alarm, Service interface: USB, Display: Backlit LCD, 4 lines, Languages: 8, Ambient temperature: -10 to 50°C, Relative humidity: 0 to 95% non-condensing, Rating/Approvals: IP65, PID process controller: Yes, Hold input: Yes, Control input: yes, Alarm contact: Yes, Measurement parameters: D.O. saturation or concentration and temperature, ISM: Plug&Measure, Advanced Diagnostics (Lifetime indicator, Adaptive calibration timer, CIP/SIP counter etc.), Measuring current (Air): 25 to 130 nA at 25°C, D.O. saturation range: 0 to 500%, D.O. concentration range: 0,00 to 20,00 ppm, Measurement error: $\pm 0,5\%$ of full scale reading, Measurement resolution: 30pA, Temperature input: NTC 22kΩ, Temperature compensation: Automatic, Temperature measuring range: -10 to 80°C, Calibration: 1-point (slope or offset calibration), process calibration (slope or offset calibration)
Order No.: M400 Type 2 (52121349)
Manufactuer/Supplier: METTLER TOLEDO/ METTLER TOLEDO

QI 004 TURBIDITY OF SUSPENSION

- .01 **Name:** Sensor of turbidity and solids SOLITAX inline sc **1 pc**
Description:
Measurement procedure: IR dual scatter light, Output: 4...20mA, Accuracy-turbidity: <1% or 0,001 FNU, Accuracy-solids: <5%, Respons time: 1-300 sec, Sample temperature: 0-40°C, Flow rate: 3m/s, Pressure range: 5bar, Weight: 2400g, Dimensions(DxL): 60x315mm, Housing: Stainless steel, Cleaning: with automatic wiper, Cable length: 10m, Type of fitting: Insertion probe
Measuring range turbidity: 0-4000 NTU
Measuring range solids: 0-50 g/l
Order No.: SOLITAX inline sc (LXV424.99.00100)
Manufactuer/Supplier: HACH LANGE/ HACH LANGE
- .02 **Name:** Inline armatura **1 pc**
Description:
Material: Stainless steel
Order No.: LZX461
Manufactuer/Supplier: HACH LANGE / HACH LANGE
- .03 **Name:** Welding flange **1 pc**
Description:
Material: Stainless steel
Order No.: LZX660
Manufactuer/Supplier: HACH LANGE / HACH LANGE
- .04 **Name:** Transmitter SC200 **1 pc**
Description:
Power supply: 110-240/50 V/Hz, Current output: 2x0/4 to 20 mA, Display: Backlit LCD, Rating/Approvals: IP66
Order No.: LXV404.99.00501
Manufactuer/Supplier: HACH LANGE / HACH LANGE

FIRC 001 FLOW OF CO2**FV 001 FLOW OF CO2**

- .01 **Name:** Digital mass flow controller **1 pc**
Description:
Power supply: 24VDC, Accuracy: $\pm 1,5\%$ of full scale including linearity over 0-50°C and 0,3-10barg, Repeatability: $\pm 0,25\%$ of full scale, Temperature coefficient: 0,05% of full scale per °C, or better, Pressure coefficient: 0,15% of full scale per bar, or better, Response time: 300ms, Process connection: 3/8", Output and setpoint signal: 4-20mA, Display: Yes, Material of body: stainless steel, Seal: Viton, Communication: RS232, Calibration: CO2, Electrical connection: Conector DB9
Order No.: C50 Series Smart-Trak®
Manufactuer/Supplier: SIERRA/ KROHNE

FIC 002 FLOW OF SUSPENSION

.01 **Name:** Electromagnetic flowmeter MAG 1100

1 pc

Description:

Measuring principle: Electromagnetic induction, Accuracy: 0,4%, Process connection: Wafer design-DN 50 mating flanges, Liner material: Ceramic Al₂O₃, Temperature of the medium: -20...150°C, Material electrodes: platinum, Housing material: polished stainless steel (AISI 316L), Protection degree: IP67

Order No.: 7ME6110-2YA20-2AA1

Manufacturer/Supplier: SIEMENS/ SIEMENS

.02 **Name:** Transmitter MAG 5000

1 pc

Description:

Power supply: 115...230V AC, Analog output: 4...20mA, Digital output: 1xrelay, 1xpulse output, Display: LCD, Accuracy: 0,4%, Ambient temperature-operation: -20...60°C, Housing material: fibre glass reinforced polyamide, Protection degree: IP67

Order No.: 7ME6910-1AA10-1AA0

Manufacturer/Supplier: SIEMENS/ SIEMENS

FS 001 ELECTRIC MOTOR FOR MAIN VALVE**FS 002 ELECTRIC MOTOR FOR BYPASS VALVE**

.01 **Name:** Electric motor

2 pc

Description:

Power supply: 24V DC

Order No.: SM24A

Manufacturer/Supplier: BELIMO/ TRIVAL

FIRC 003 FLOW WATER

.01 **Name:** Ultrasonic flowmeter

1 pc

Description:

Static ultrasonic water meter for accurate measuring and recording for all applications of water supply. Medium temperature range: 1...50°C, Ambient operating temperature: 1...70°C, Nominal pressure 16bar, Power supply: two 3,6 VDC lithium batteries, Battery lifetime: up to 16 years, Interfaces: two pulse output, Display: LCD-8digit, Unit: m³/h-l/h-m³-l-°C-F-h-d, Accuracy: higher than class D, Connection: DN20, G1", Material: brass

Nominal flow rate: 4 m³/h

Order No.: HYDRUS-Q3 4 DN20/130 G 1" R250 OM (3033693)

Manufacturer/Supplier: HYDROMETER/ ENBRA

FS 003	SOLENOID VALVE FOR WATER TO TANK
FS 004	1. SOLENOID VALVE FOR GLASS CLEANING
FS 005	2. SOLENOID VALVE FOR GLASS CLEANING
FS 006	3. SOLENOID VALVE FOR GLASS CLEANING
FS 007	4. SOLENOID VALVE FOR GLASS CLEANING

.01 **Name:** Solenoid valve

5 pc

Description:

Power supply 24 V DC

Order No.: 2VE25DA-N1

Manufacturer/Supplier: BELIMO/ TRIVAL

2. Control Cubicle

A. Control cubicle

- .01 **Name:** Control cubicle **1 pc**
Description:
Dimension(WxHxD): 800x1000x300 mm, Material: Stainless steel
Order No.: IRIS-LT 810.30
Manufactuer/Supplier: KM RACK/ KM RACK

B. Control systém PLC

- .01 **Name:** S7 MICRO MEMORY CARD, 128KB **1 pc**
Description:
SIMATIC S7, MICRO MEMORY CARD FUER S7-300/C7/ET 200, 3,3 V NFLASH, 128KBYTE
Order No.: 6ES7953-8LG20-0AA0
Manufactuer/Supplier: SIEMENS/ SIEMENS
- .02 **Name:** STARTER KIT TP1200 COMFORT **1 pc**
Description:
TP1200 COMFORT, WINCC COMFORT (TIA PORTAL)
Order No.: 6AV2181-4MB00-0AX0
Manufactuer/Supplier: SIEMENS/ SIEMENS
- .03 **Name:** CPU317-2 PN/DP, 1MB **1 pc**
Description:
SIMATIC S7-300 CPU 317-2 PN/DP, 1 MPI/DP 12MBIT/S, 2 ETHERNET PROFINET WITH 2 PORT SWITCH
Order No.: 6ES7317-2EK14-0AB0
Manufactuer/Supplier: SIEMENS/ SIEMENS
- .04 **Name:** Digital input/output module SM323 **1 pc**
Description:
16DI/16DO, DC 24V, 0,5A
Order No.: 6ES7323-1BL00-0AA0
Manufactuer/Supplier: SIEMENS/ SIEMENS
- .05 **Name:** Analog input module SM331 **1 pc**
Description:
8AI, 13BIT
Order No.: 6ES7331-1KF02-0AB0
Manufactuer/Supplier: SIEMENS/ SIEMENS
- .06 **Name:** Analog input/output module SM334 **1 pc**
Description:
4AI/2AO, 12BIT
Order No.: 6ES7334-1KE00-0AB0
Manufactuer/Supplier: SIEMENS/ SIEMENS

- | | | |
|-----|--|-------------|
| .07 | Name: SIMATIC S7-300 Rail
Description:
Rail L=480mm
Order No.: 6ES7390-1AE80-0AA0
Manufactuer/Supplier: SIEMENS/ SIEMENS | 1 pc |
| .08 | Name: Power Source SITOP PSU100L 24V/10A
Description:
INPUT: AC 120/230V, OUTPUT: DC 24V/10A
Order No.: 6EP1334-1LB00
Manufactuer/Supplier: SIEMENS/ SIEMENS | 1 pc |
| .09 | Name: SIMATIC S7-300 Front connector 20pin
Description:
Front connector 20pin
Order No.: 6ES7392-1BJ00-0AA0
Manufactuer/Supplier: SIEMENS/ SIEMENS | 1 pc |
| .10 | Name: SIMATIC S7-300 Front connector 40pin
Description:
Front connector 40pin
Order No.: 6ES7392-1BM00-0AA0
Manufactuer/Supplier: SIEMENS/ SIEMENS | 2 pc |

C. Other devices in control cubicle

- | | | |
|-----|---|---|
| .01 | Name: General purpose AC drive
Description:
Power supply 200-240V $\pm 10\%$, 48-62Hz
Order No.: Commander SK (SKA1200037)
Manufactuer/Supplier: CONTROL TECHNIQUES/ CONTROL TECHNIQUES | 1 pc |
| .02 | Name: Relays -K1...-K8
Description:
Relé Microseries 24VDC 1CO
Order No.: Commander Relé Microseries 24VDC 1CO (8533660000)
Manufactuer/Supplier: WEIDMÜLLER/ WEIDMÜLLER | 8 pc |
| .03 | Name: Breakers -FA1...-FA7
Description:
-FA1- 10A C
-FA2, -FA6- 2A B
-FA3- 10A B
-FA4, FA7- 6A B
-FA5- 4A B
Order No.: MERLIN GERLIN
Manufactuer/Supplier: MERLIN GERLIN/ ELKOV | 1 pc
2 pc
1 pc
2 pc
1 pc |

-
- .04 **Name:** RESIDUAL CURRENT CIRCUIT BREAKERS WITH OVERCURRENT PROTECTION -FA8
Description:
 -FA8- 10A B **1 pc**
Order No.: OLE-10B-1N-030AC (38314)
Manufacturer/Supplier: OEZ/ ELKOV
- .05 **Name:** SURGE PROTECTION WITH CONNECTOR
Description:
 -OF1- Type 3 arrester replacement connector (device protection) for 1-phase power supply networks with separate N and PE (3-conductor system: L1, N, PE).
 Base element for protective plug PT, for mounting on NS 35/7.5 and NS 35/15, housing width: 17.5 mm
Order No.: PT2-PE/S-230AC-ST (2839347) **1 pc**
Order No.: PT-BE/FM (2839282) **1 pc**
Manufacturer/Supplier: PHOENIX CONTACT/ PHOENIX CONTACT
- .06 **Name:** Main switch -Q1 **1 pc**
Description:
 Cam switch 25A
Order No.: VSN25 1103A8-V-NVZ3R
Manufacturer/Supplier: OBZOR/ ELKOV
- .07 **Name:** Compact Lamp with electrical swiss socket -H1 **1 pc**
Description:
 Compact Lamp with electrical swiss socket
Order No.: KL 025 (02502.0-00)
Manufacturer/Supplier: STEGO/ GHV
- .08 **Name:** Socket outlet -H2 **1 pc**
Description:
 Socket outlet DIN ("SCHUKO"), Connection-bottom
Order No.: ZSF-03 (37292)
Manufacturer/Supplier: STEGO/ GHV
- .09 **Name:** Transmitter **1 pc**
Description:
 DIN Rail Housing, Connecting terminals removable, Loop powered 12 V DC ... 35 V DC, Input: 0 ... 20 mA/ 0 ... 10 V, Output: 4 ... 20 mA, 1 channel
Order No.: KFD0-CC-1 (038310)
Manufacturer/Supplier: PEPPERL+FUCHS/ PEPPERL+FUCHS
- .10 **Name:** Terminals -X1...-X6
Description:
 Terminals P-series, Feed-through terminal, Rated cross-section: 4 mm², PUSH IN
Order No.: PDU 2.5/4 (1896110000)
Manufacturer/Supplier: WEIDMÜLLER/ WEIDMÜLLER

Unit for cultivation of microalgae – Electrical part

1. Technical report

Content

1. SUBJECT OF THE PROJECT.....	2
1.1 ELECTRICAL PROJECT CONTAINS:	2
1.2 PROJECT DOCUMENTS:	2
2. CONTROL SYSTEM OF INSTRUMENTATION	2
3. REVIEW OF REGULATION CIRCUITS NEEDED FOR CONTROL OF THE PLATFORM	2
3.1 SUPPLY OF WATER IN THE TANK	2
3.2 REGULATION OF WATER LEVEL IN THE PLATFORM	2
3.3 REGULATION OF PUMP SPEED	3
4. PLC CONTROL SYSTEM.....	3
5. SWITCHBOARD CJK01 OF INSTRUMENTATION AND ELECTRIC PART	3
5.1 SWITCHBOARD EXECUTION.....	3
5.2 OVERCURRENT PROTECTION.....	3
5.3 PROTECTION AGAINST OVERVOLTAGE	4
5.4 EL. ENERGY CONSUMPTION MEASURING.....	4
5.5 POWER FACTOR CORRECTION.....	4
5.6 EARTHING AND PROTECTION AGAINST ELECTRIC SHOCK	4
5.7 DIRECTIONAL MARKING OF CONDUCTORS	5
6. FIELD INSTRUMENTATION, USED DEVICES	5
6.1 PRESSURE MEASUREMENT – CONTINUOUS MEASUREMENT	5
6.2 WATER LEVEL MEASUREMENT – CONTINUOUS MEASUREMENT OF WATER LEVEL	5
HEIGHT IN THE TANK	5
6.3 WATER LEVEL MEASUREMENT – CONTINUOUS MEASUREMENT OF WATER LEVEL HEIGHT ON THE	5
PLATFORM	5
6.4 MEASUREMENT OF ALGAE SUSPENSION FLOW	6
6.5 MEASUREMENT OF CO ₂ FLOW	6
6.6 MEASUREMENT OF WATER FLOW	6
6.7 TEMPERATURE MEASUREMENT	6
6.8 PH, O ₂ , PCO ₂ AND TURBIDITY MEASUREMENT	6
6.9 ACTION ELEMENTS	6
7. SIGNAL LINE OF CONTROL SYSTEM OF CULTIVATION PLATFORM.....	6
7.1 CABLING DISTRIBUTION.....	6
7.2 DIRECTIONAL MARKING OF CABLES	7
8. ENERGY CONSUMPTION OF CONTROL SYSTEM OF INSTRUMENTATION AND	7
ELECTRIC PART:	7
9. REQUIREMENTS FOR OTHER PROFESSIONS	7
10. SAFETY AT WORK AND HEALTH PROTECTION.....	7

1. Subject of the project

1.1 Electrical project contains:

the project solves the switchboard **CJK01** for control of platform for cultivation of microalgae. Further the project solves cable leads for the installed equipment.

1.2 Project documents:

customer requirements
mechanical engineering and technological drawings and documentation
regulations and valid standards for equipment placed in the building

2. Control system of instrumentation

Control system of the platform for cultivation of microalgae consists of control system PCL Simatic S7/300 located in the switchboard **CJK01**. All control takes place here. Monitoring of platform condition is carried out through local and remote devices and sensors. Obtained data are concentrated in control system PLC which evaluates and control platform operation by means of regulating loops. LPC program evaluates operational and emergency conditions and implements appropriate interventions. All signals, alarms and emergency conditions are transferred into the operator station and will be archived. Control program is stored in logic controller memory and after starting by an operator works fully autonomously. Operator station is placed at the door of the switchboard **CJK01**. As visualization software is used WinCC Flexible. Operator monitors operation of the platform on the screen. All measured values will be archived in the operation panel.

3. Review of regulation circuits needed for control of the platform

3.1 Supply of water in the tank

System of water level regulation is carried out by PLC logic. All control takes place here. Monitoring of water level height is carried out through a local water level probe LMK 351. The system evaluates critically low threshold water level at which the pump is switched off in order to prevent suction of air. Another threshold water level is operational. When through evaporation this level is reduced, the system automatically supplies water into the tank. Further is measured max. water level in the tank full of suspense.

3.2 Regulation of water level in the platform

Suspension level regulation on the platform is carried out by PLC control logic. Monitoring of suspension level on the platform is carried out through local level ultrasound probe UB 120-12GM-I-VI. The system evaluates the actual water level on the platform. Operator enters the desired height of water level in mm and the system regulates automatically the speed of the pump in order to achieve the required water level.

3.3 Regulation of pump speed

Regulation of pump speed is carried out by PCL control logic. Monitoring of pressure on the pump delivery is carried out through local pressure probe DMK 331. The system evaluates actual pressure at the pump delivery and regulates automatically the pump speed.

4. PLC control system

PLC control system Simatic S7/300 is selected from the range for fully integrated automation. It is a extensible compact microsystem with a simple programming for basic automation tasks with high degree of PLC functions and with a possibility to work separately or in the net applications. Programming is made by means of development environment Siemens Step 7. Control system modules are assembled on a common basic bar.

Extensibility enables adaptation for given specific solution. It has communication interface with protocol Profibus DP and the net communication Ethernet/Profinet. Communication speed is up to 12Mb/s on Profibus DP and 10/100 Mb/s on Ethernet/Profinet. Drives and remote controlled fittings are controlled through isolating relay. Control system PLC communicates with operator panel over the line Ethernet with protocol Profinet, for physical layer is used metallic cable. Supply of inputs and outputs voltage is 24V DC.

Working conditions $0^{\circ}\text{C} \div 55^{\circ}\text{C}$, storage temperature $-40^{\circ}\text{C} \div +70^{\circ}\text{C}$, relativ humidity 95% noncondensing.

Control system Simatic S7/300 is located in the switchboard **CJK01**.

5. Switchboard CJK01 of instrumentation and electric part

5.1 Switchboard execution

Switchboard of instrumentation and electrical part have a common cabinet. The switch board will be placed in the greenhouse, attached to the platform structure. Switchboard dimensions are HxWxD 1000x800x300 mm. Switchboard has wall stainless steel execution with cover IP 54/00. Outlets are made from the bottom. Switchboard is equipped with protection outlets designed to protect or disconnect feeding of circuits. Main switch of the switchboard is of a cam type with control lever on the site of the switchboard cabinet. Switchboard is equipped with circuit breakers, sockets, lighting and supply source 24VDC for control system PLC and field instrumentation. Switchboard feeding is made by connecting current supply from the switchboard provided by the customer. Supply voltage is 230 V/50 Hz is in the switchboard branched off for feeding the switchboard and individual parts of field instrumentation. Inlet feeding circuit must not be equipped with residual current circuit breaker with residual current $\leq 30\text{mA}$ due to possible ground leakage current of used frequency converter up to 20mA.

5.2 Overcurrent protection

Overcurrent protection of circuits and consumers will be performed by circuit breakers, which will be placed in switchboard.

5.3 Protection against overvoltage

Installed equipment and devices are of category III (4kV) according to EN 60664-1 requiring SPDT1. These SPDT1 are presumed to be located in power supply point of the customer.

5.4 El. energy consumption measuring

Consumption will be measured on the customer side.

5.5 Power factor correction

Power factor compensation of powered consumers within this project is not solved, it is presumed to be central in the power supply point.

5.6 Earthing and protection against electric shock

Within protection it is necessary to execute supplementary equipotential bonding of steel structure of the platform with protective earthing busbar of the switchboard **CJK01** by conductor CYA2,5.

Earthing terminal FM in the switchboard is necessary to connect by two parallel conductors according to assembly instruction of FM manufacturer.

El. power supply system	1 NPE ~ 50 Hz 230 V / TN-S 2 – 24 V/IT (for signaling and control)
-------------------------	---

Installed power:	0,5 kW
Concurrent factor	1,0
Rated power	0,5 kW
Power factor	0,9

Protection against injury by el. shock according to CSN 61140 ed.2 and CSN 332000-4-4 ed.2:

1. Protective measure: automatic disconnection from the source according to 411 including:
 - BASIC PROTECTION (protection against dangerous touch of live parts) – by basic insulation and covers according to 411.2 and as per Annex A
 - FAULT PROTECTION (protection against dangerous touch of dead parts – by protective connection and automatic disconnection from the source by overcurrent protective elements according to 411.3 in the net 1 NPE ~ 50 Hz 230V/TN-S according to 411.4
 - ENHANCED PROTECTION – by additional connection and current protector as per 415
2. Protective measures: protection through low voltage according to 414 in the net 2 – 24V DC/SELV

Protection against electrical shock by EN 61140 and HD 60364-4-41:2007 :

1. Supply system 1 NPE ~ 230V 50Hz / TN-S:

Protection measure: automatic disconnection of supply taken in:

- BASIC PROTECTION (protection against direct contact) - basic insulation and enclosures
- FAULT PROTECTION (protection against indirect contact) - protective-equipotential-bonding and automatic disconnection of supply in the network TN-S
- ENHANCED PROTECTIVE - supplementary equipotential bonding, residual current circuit breakers

2. Supply 2 – 24V / IT:
- extra-low voltage SELV

Voltage in the control circuits of instrumentation is 24V DC, PELV, live parts are not connected with live parts of other circuits. Protection against dangerous touch with live and dead parts is by low voltage. Protection against dangerous touch with live parts is by insulation and covers. This protection is in control circuits of instrumentation. In power circuits is protection against overcurrents ensured by use of protective measures against overcurrents (circuit breakers in feeding switchboard, circuit breakers in control cabinets). Protection against dangerous touch with dead parts in power distribution is made by automatic disconnection from the source, insulation and connection.

Environment impacts:

HD 60364-5-51:2009 defines room in the building as:

Extra dangerous – environments: **AB6**, AD4, BC2 other Ax1, Bx1, Cx1:

5.7 Directional marking of conductors

Sleeves at the end of conductors describe the place of connection:
busbar terminal or device terminal

6. Field instrumentation, used devices

6.1 Pressure measurement – continuous measurement

For pressure measurement is used sensor without programming for direct pressure measurement. Pressure sensor with outlet 0-10 V is connected directly to control system.

6.2 Water level measurement – continuous measurement of water level height in the tank

For continuous measurement of water level in the tank is used pressure sensor with outlet 0÷10 V which is directly connected to the control system.

6.3 Water level measurement – continuous measurement of water level height on the platform

For continuous measurement of suspension level on the platform is used ultrasound sensor with outlet 4-20 mA which is directly connected to the control system.

6.4 Measurement of algae suspension flow

For measurement of algae suspension flow is used induction flow meter with outlet 4-20 mA which is directly connected with the control system.

6.5 Measurement of CO₂ flow

For measurement of CO₂ flow is used thermal mass flow meter with regulator. Outlet 4-20 mA is directly connected with the control system.

6.6 Measurement of water flow

For measurement of water flow is used ultrasound water meter with two impulse outlets which is directly connected with the control system.

6.7 Temperature measurement

For temperature measurement is used resistance indicator Pt1000. Indicator forms a part of pH probe and is directly connected to the converter in the switchboard. Outlet 4-20 mA from the converter is directly connected to the control system.

6.8 pH, O₂, pCO₂ and turbidity measurement

For pH, O₂, pCO₂ and turbidity measurement are used special probes. The probes are directly connected to the converter in the switchboard. Outlets from the converter 4-20 mA are directly connected to the control system.

6.9 Action elements

Electric drives and solenoid valves are controlled through transmission relays. Electric drive of the pump is controlled through frequency converter.

7. Signal line of control system of cultivation platform

7.1 Cabling distribution

Cabling distribution of the control system of instrumentation will be executed in hot-dip galvanized cable channels, on cable racks, to individual devices in bundles or in galvanized pipes with correspondent corrosion resistance due to the environment or in plastic hoses. Cables are according to voltage level led separately in individual channels for:

routes for signals 24 V DC, 4-20 mA

routes for feeding and signals 230 V, 50 Hz

Main routes for signals 24 V DC, 4-20 mA are led in a separate cable channel parallel with routes 230 V, 50 Hz with min. distance 200 mm from these routes. Crossing of both routes is perpendicular. For feeding cabling is due to small number of cables for signals 230 V, 50 Hz presumed using of free cable racks or channels of electric part.

7.2 Directional marking of cables

Labels at the end of the cable are 4-lines and describe:

- 1. line – connection of remote end
- line – cable name (KKS)
- line – cable type
- line – connection of close end

8. Energy consumption of control system of instrumentation and electric part:

Electricity

Electricity supply to the control system of instrumentation and field instrumentation:

1f. 230V, ~50 Hz, 1 kW

9. Requirements for other professions

Mechanical engineering part

Mechanical engineering part will ensure equipment connection of control system of instrumentation according to process flow sheet and drawings of withdrawals. It shall ensure welding of welded-on pieces of piping and holders for sensors. It shall also ensure execution of supports for bridging of great distances on steel structures for cable routes.

Civil engineering part

Within civil engineering works will be made passages through the wall for cable routes which will be after installation properly closed according to fire safety requirements.

10. Safety at work and health protection

Electrical installation must be executed in accordance with valid ČSN standards, must be attended and operated according to corresponding working and operational regulations of ČSN and manufacturer instructions in order to ensure safety at work and health protection and protection of property.

If electrical equipment and distributions are not properly handed or damaged there is danger of injury by electric shock. In order to prevent injury or fire is necessary to keep el. equipment and distributions in good technical condition and proceed in maintenance in accordance with the corresponding standards.

Operators must be made familiar with location and function of main switch. Attendance of el. equipment can be only carried out by persons with appropriate qualification.

Switchboard must be equipped with danger signs according to corresponding standards. After installation the installer shall ensure initial inspection and elaboration of inspection report.



BCS Engineering, a.s.

Purkyňova 79a

Brno

+420 541 597 111

Company / Customer: Zürich University of Applied Sciences ZHAW

Project Number:	1798
-----------------	------

Job number 1798 DA5 001

Final user: Zürich University of Applied Sciences ZHAW

Type: Control cubicle for unit for the Cultivation of Microalgae


Last edit date: 20.12.2012


Elaborated by: Ing. Harašta

Revised by: Ing. Kincl

Approved by: Ing. Kostelník

Number of pages 27

				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - COVER SHEET	1798 DA5 001		=				
				Drawn	Ing. Harašta						+CJK01				
				Checked	Ing. Kinkl										
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník					1798		Sheet 1			
												Next 2			
1		2		3		4		5		6		7		8	





CONTROL CUBICLE

CJK01

CUBICLE DIMENSION AND LAYOUT

				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - DIMENSION AND LAYOUT	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	2
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník					1798	Next	3





				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - LAYOUT	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl							
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník							
1			2		3		4	5	6	7	1798	Sheet 4
												Next 5


CONTROL CUBICLE


CJK01

PLC CONFIGURATION

				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - PLC CONFIGURATION	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	5
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	6




				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - RACK	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	6
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	7





CONTROL CUBICLE


CJK01


WIRING I/O MODULES


				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - WIRING I/O MODULES	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	7
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	8



				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - CONNECTION OF MODULE DI/DO	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl							
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník					1798	Sheet	8
											Next	9




				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - CONNECTION OF MODULE AI	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl							
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník					1798	Sheet	9
											Next	10





CONTROL CUBICLE


CJK01


POWER SUPPLY WIRING DIAGRAMS

				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - POWER SUPPLY WIRING DIAGRAMS	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	11
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	12



				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - SUPPLY VOLTAGE 230V/50HZ	1798 DA5 001		=			
				Drawn	Ing. Harašta						+CJK01			
				Checked	Ing. Kindl									
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník						1798		Sheet	12
													Next	13



				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - SUPPLY VOLTAGE 24V DC	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	13
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	14

1

2

3


4


5

6

7

8



				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - WIRING DIAGRAMS OF ANALOG I/O	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	14
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	15

A





F


1




1





				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - FLOW CO2 AND SUSPENSION, LEVEL OF SUSPENSION ON PLATFORM	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kincl							
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Sheet	16
1											Next	17





				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - LEVEL IN TANK, PRESSURE, PUMP	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl							
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník					1798		Sheet 17
												Next 18




				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - WIRING DIAGRAMS OF DI/DO	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	18
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník					1798	Next	19



				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - DI-pCO2, pH, TEMPERATURE, O2, TURBIDITY	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kincl						Sheet	19
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	20




				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - DI-FLOW WATER AND RESERVES	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	20
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	21




CONTROL CUBICLE

CJK01

WIRING DIAGRAMS COMMUNICATION

				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - COMMUNICATION	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl						Sheet	23
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798		Next	24
1			2		3		4	5	6	7	8	



				Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	CONTROL CUBICLE - PROFIBUS DP AND ETHERNET	1798 DA5 001		=	
				Drawn	Ing. Harašta						+CJK01	
				Checked	Ing. Kindl							
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník					1798		Sheet 24
												Next +/-


1		2		3		4		5		6		7		8			
Table of contents								Column X: An automatically generated page was edited								F06_001	
Page		Page description						supplementary page field		Date		Edited by		X			
=+CJK01/1		CONTROL CUBICLE - COVER SHEET								18.12.2012		HARAŠTA		X			
=+CJK01/2		CONTROL CUBICLE - DIMENSION AND LAYOUT								18.12.2012		HARAŠTA		X			
=+CJK01/3		CONTROL CUBICLE - DIMENSIONS FOR MANUFACTURE								18.12.2012		HARAŠTA					
=+CJK01/4		CONTROL CUBICLE - LAYOUT								18.12.2012		HARAŠTA					
=+CJK01/5		CONTROL CUBICLE - PLC CONFIGURATION								18.12.2012		HARAŠTA		X			
=+CJK01/6		CONTROL CUBICLE - RACK								20.12.2012		HARAŠTA					
=+CJK01/7		CONTROL CUBICLE - WIRING I/O MODULES								18.12.2012		HARAŠTA		X			
=+CJK01/8		CONTROL CUBICLE - CONNECTION OF MODULE DI/DO								20.12.2012		HARAŠTA					
=+CJK01/9		CONTROL CUBICLE - CONNECTION OF MODULE AI								20.12.2012		HARAŠTA					
=+CJK01/10		CONTROL CUBICLE - CONNECTION OF MODULE AI/AO								20.12.2012		HARAŠTA					
=+CJK01/11		CONTROL CUBICLE - POWER SUPPLY WIRING DIAGRAMS								18.12.2012		HARAŠTA		X			
=+CJK01/12		CONTROL CUBICLE - SUPPLY VOLTAGE 230V/50HZ								20.12.2012		HARAŠTA					
=+CJK01/13		CONTROL CUBICLE - SUPPLY VOLTAGE 24V DC								20.12.2012		HARAŠTA					
=+CJK01/14		CONTROL CUBICLE - WIRING DIAGRAMS OF ANALOG I/O								18.12.2012		HARAŠTA		X			
=+CJK01/15		CONTROL CUBICLE - AI-pCO2, pH, TEMPERATURE, O2, TURBIDITY								20.12.2012		HARAŠTA					
=+CJK01/16		CONTROL CUBICLE - FLOW CO2 AND SUSPENSION, LEVEL OF SUSPENSION ON PLATFORM								20.12.2012		HARAŠTA					
=+CJK01/17		CONTROL CUBICLE - LEVEL IN TANK, PRESSURE, PUMP								20.12.2012		HARAŠTA					
=+CJK01/18		CONTROL CUBICLE - WIRING DIAGRAMS OF DI/DO								18.12.2012		HARAŠTA		X			
=+CJK01/19		CONTROL CUBICLE - DI-pCO2, pH, TEMPERATURE, O2, TURBIDITY								20.12.2012		HARAŠTA					
=+CJK01/20		CONTROL CUBICLE - DI-FLOW WATER AND RESERVES								20.12.2012		HARAŠTA					
=+CJK01/21		CONTROL CUBICLE - SOLENOID VALVES AND RESERVE								20.12.2012		HARAŠTA					
=+CJK01/22		CONTROL CUBICLE - VALVES WITH MOTOR, AC DRIVER AND RESERVES								20.12.2012		HARAŠTA					
=+CJK01/23		CONTROL CUBICLE - COMMUNICATION								18.12.2012		HARAŠTA		X			
=+CJK01/24		CONTROL CUBICLE - PROFIBUS DP AND ETHERNET								20.12.2012		HARAŠTA					
=+/1		Table of contents : =+CJK01/1 - =+/3								20.12.2012		HARAŠTA					
=+/2		Cable overview : =+CJK01-W1 - =+CJK01-W21								20.12.2012		HARAŠTA					
=+/3		Parts list : SIE.6ES7390-1AE80-0AA0 - WEI.MRZ 24VDC 1CO								20.12.2012		HARAŠTA					

1		2		3		4		5		6		7		8					
Cable overview														F10_001					
Cable name		Source (from)		Target (to)		cable type		all conductors		Conductors used		Cross-section [mm]		Length [m]		function text		Graphical page of cable diagram	
+CJK01-W1						CYKY-J 3x2,5		3		0		2,5		20					
+CJK01-W2		+CJK01-FIC_002-X1		+CJK01-X2		CYKY-J 3x1,5		3		3		1,5		3		230VAC 50Hz			
+CJK01-W3		+CJK01-X3		+CJK01-M		CYKY-J 4x2,5		4		5		2,5		3		=			
+CJK01-W4		+CJK01-QIC_001-X1		+CJK01-B1		JQTQ-O 2x0,8		2		2		0,8		5					
+CJK01-W5		+CJK01-QIC_002TI_001-X1		+CJK01-B2		JQTQ-O 2x0,8		2		2		0,8		5					
+CJK01-W6		+CJK01-QI_003-X1		+CJK01-B3		JQTQ-O 2x0,8		2		2		0,8		5					
+CJK01-W7		+CJK01-QI_004-X1		+CJK01-B4		JQTQ-O 2x0,8		2		2		0,8		5					
+CJK01-W8		+CJK01-FIRC_001FV_001-DB9		+CJK01-X4		JQTQ-O 2x0,8		2		9		0,8		3					
+CJK01-W9		+CJK01-X4		+CJK01-FIC_002-QI_003		JQTQ-O 2x0,8		2		2		0,8		3					
+CJK01-W10		+CJK01-LISA_002-M12		+CJK01-X4		JQTQ-O 2x0,8		2		4		0,8		10					
+CJK01-W11		+CJK01-LISA_001-ISO4400		+CJK01-X4		JQTQ-O 2x0,8		2		3		0,8		5					
+CJK01-W12		+CJK01-PIC_001-ISO4400		+CJK01-X4		JQTQ-O 2x0,8		2		3		0,8		3					
+CJK01-W13		+CJK01-X5		+CJK01-FIRC_003		JQTQ-O 2x0,8		4		4		0,8		1,5					
+CJK01-W14		+CJK01-FS_003-ISO4400		+CJK01-X6		JQTQ-O 2x0,8		2		2		0,8		10					
+CJK01-W15		+CJK01-FS_004-ISO4400		+CJK01-X6		JQTQ-O 2x0,8		2		2		0,8		10					
+CJK01-W16		+CJK01-FS_005-ISO4400		+CJK01-X6		JQTQ-O 2x0,8		2		2		0,8		10					
+CJK01-W17		+CJK01-FS_006-ISO4400		+CJK01-X6		JQTQ-O 2x0,8		2		2		0,8		10					
+CJK01-W18		+CJK01-FS_007-ISO4400		+CJK01-X6		JQTQ-O 2x0,8		2		2		0,8		10					
+CJK01-W19		+CJK01-FS_001		+CJK01-X6		JQTQ-O 3x0,8		2		3		0,8		3					
+CJK01-W20		+CJK01-FS_002		+CJK01-X6		JQTQ-O 3x0,8		2		3		0,8		3					
+CJK01-W21		+CJK01-OP-X1		+CJK01-R1-A10		ETHERNET CABLE		1x2		1		0,64		2					

Parts list

F01_001

device tag	Quantity	designation	Type number	supplier	part number
+CJK01-R1	1	SIMATIC S7-300, Rail; L=480mm	6ES7390-1AE80-0AA0	SIEMENS	SIE.6ES7390-1AE80-0AA0
+CJK01-R1-A10	1	SIMATIC S7-300, CPU 317-2 PN/DP	6ES7317-2EK14-0AB0	SIEMENS	SIE.6ES7317-2EK14-0AB0
+CJK01-R1-A20	1	SIMATIC S7-300, digital input / output module SM 323	6ES7323-1BL00-0AA0	SIEMENS	SIE.6ES7323-1BL00-0AA0
+CJK01-R1-A30	1	SIMATIC S7-300, analog input SM 331	6ES7331-1KF02-0AB0	SIEMENS	SIE.6ES7331-1KF02-0AB0
+CJK01-R1-A40	1	SIMATIC S7-300, analog output module SM 334	S7	SIEMENS	SIE.6ES7334-0KE00-0AB0
+CJK01-Q1	1	Main switch	VSN25 1103A8-V-NVZ3R	ELKOV	OBZOR.VSN25_1103A8-V-NVZ3R
+CJK01-PS	1	SITOP PSU100L 24V/10 A, INPUT 230V AC	6EP1334-1LB00	SIEMENS	SIE.6EP1334-1LB00
+CJK01-OF	1	SURGE PROTECTION	PT 2-PE/S-230AC-ST	Phoenix Contact	PHO.PT 2-PE/S-230AC-ST
+CJK01-OF	1	CONNECTOR FOR SURGE PROTECTION	PT-BE/FM	Phoenix Contact	PHO.PT-BE/FM
+CJK01-FA1	1	Breaker 10A / C	OEZ.LPE-10C-1	REXEL	OEZ.LPE-10C-1
+CJK01-FA8	1	RESIDUAL CURRENT CIRCUIT BREAKERS WITH OVERCURRENT PROTECTION	OLE-10B-1N-030AC	REXEL	OEZ.OLE-10B-1N-030AC
+CJK01-H1	1	Compact Lamp with electrical swiss socket	KL 025	GHV	STEGO.KL 025
+CJK01-H2	1	Socket outlet DIN ("SCHUKO"), Connection-bottom	ZSF-03	OEZ	OEZ.ZSF-03
+CJK01-QIC_001	1	Transmitter M400 Type 3	M400 Type 3	METTLER TOLEDO	MT.M400_Type 3
+CJK01-QIC_002TI_001	1	Transmitter M300	M300	METTLER TOLEDO	MT.M300
+CJK01-QI_003	1	Transmitter M400 Type 2	M400 Type 2	METTLER TOLEDO	MT.M400_Type 2
+CJK01-QI_004	1	Transmitter SC200	SC200	HACH LANGE	HACH_LANGE.SC200
+CJK01-FIC_002	1	Electromagnetic flowmeter MAG 1100	MAG 1100	SIEMENS	SIEMENS.MAG 1100
+CJK01-FA2	1	Breaker 2A / B	OEZ.LPE-2B-1	REXEL	OEZ.LPE-2B-1
+CJK01-MCA_001	1	General purpose AC drive	Commander SK	CT	CT.Commander SK
+CJK01-M	1	ELECTRIC MOTOR FOR PUMP	NB40	GRUNDFOS	GRUNDFOS.NB40
+CJK01-FA3	1	Breaker 10A / B	OEZ.LPE-10B-1	REXEL	OEZ.LPE-10B-1
+CJK01-OP	1	OPERATOR PANEL TP1200	TP1200	SIEMENS	SIE.TP1200
+CJK01-FA4	1	Breaker 6A / B	OEZ.LPE-6B-1	REXEL	OEZ.LPE-6B-1
+CJK01-FA5	1	Breaker 4A / B	OEZ.LPE-4B-1	REXEL	OEZ.LPE-4B-1
+CJK01-FA6	1	Breaker 2A / B	OEZ.LPE-2B-1	REXEL	OEZ.LPE-2B-1
+CJK01-FA7	1	Breaker 6A / B	OEZ.LPE-6B-1	REXEL	OEZ.LPE-6B-1
+CJK01-B1	1	SENSOR pCO2	InPro5000i/12/120	METTLER TOLEDO	MT.InPro5000i/12/120
+CJK01-B2	1	SENSOR pH	InPro3253i/SG/120	METTLER TOLEDO	MT.InPro3253i/SG/120
+CJK01-B3	1	SENSOR O2	InPro6860i/12/120	METTLER TOLEDO	MT.InPro6860i/12/120
+CJK01-B4	1	TURBIDITY SENSOR	SOLITAX inline sc	HACH LANGE	HACH_LANGE.SOLITAX inline sc
+CJK01-T1	1	TRANSMITTER	KFD0-CC-1	PEPPERL FUCHS	PEP.KFD0-CC-1
+CJK01-FIRC_001FV_001	1	DIGITAL MASS FLOW CONTROLLER	C50	KROHNE	SIERRA_C50
+CJK01-LISA_002	1	ULTRASONIC SENSOR	UB120-12GM-I-V1	PEPPERL FUCHS	PEP.UB120-12GM-I-V1
+CJK01-LISA_001	1	LEVEL SENSOR	LMK 351	JSP	BD.LMK 351
+CJK01-PIC_001	1	PRESSURE SENSOR	DMK 331	JSP	BD.DMK 331
+CJK01-FS_003	1	SOLENOID VALVE	2VE25DA	BELIMO	BELIMO_2VE25DA
+CJK01-K3	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-FS_004	1	SOLENOID VALVE	2VE25DA	BELIMO	BELIMO_2VE25DA
+CJK01-K4	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-FS_005	1	SOLENOID VALVE	2VE25DA	BELIMO	BELIMO_2VE25DA
+CJK01-K5	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-FS_006	1	SOLENOID VALVE	2VE25DA	BELIMO	BELIMO_2VE25DA
+CJK01-K6	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-FS_007	1	SOLENOID VALVE	2VE25DA	BELIMO	BELIMO_2VE25DA
+CJK01-K7	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-K8	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-FS_001	1	ELECTRIC MOTOR FOR VALVE	SM24A	BELIMO	BELIMO.SM24A
+CJK01-K1	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-FS_002	1	ELECTRIC MOTOR FOR VALVE	SM24A	BELIMO	BELIMO.SM24A
+CJK01-K2	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-K9	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO
+CJK01-K10	1	Relay Microseries 24VDC 1CO	Relé:MRZ 24VDC 1CO(8533660000)	WEI	WEI.MRZ 24VDC 1CO

			Date	20.12.2012		Customer: Zürich University of Applied Sciences ZHAW	SPECIFICATIONS : SIE.6ES7390-1AE80-0AA0 - WEI.MRZ 24VDC 1CO	1798 DA5 001		=
			Drawn	Ing. Harašta						
			Checked	Ing. Kincl						
Rev.No.	Description	Date	Name	Approval	Ing. Kostelník				1798	Sheet 3 Next